

Inactive
Out of Calculation
De-energized

Voltages / Loading

Lower Voltage Range

1, p.u.

...

0,95 p.u.

...

0,9 p.u.

Upper Voltage Range

1, p.u.

...

1,05 p.u.

...


1,1 p.u.

Loading Range

80, %

...

100, %



Load Flow Balanced	
Nodes	Branches
Line-Line Voltage, Magnitude [kV]	Active Power [MW]
Voltage, Magnitude [p.u.]	Reactive Power [Mvar]
Voltage, Angle [deg]	Current, Magnitude [kA]

PowerFactory 15.1.2	Project:	
	Graphic: Providencia	
	Date: 5/26/2025	
		Annex: